



Benaming	Artikelnr.	Spuittipgrootte												
		0,3	0,5	0,8	1,0	1,2	1,5	1,8	2,0	2,2	2,5	3,0	3,5	
<b>FineSpray 03-spuittipsets</b>														
FS 03 / HP (bovenbeker)	3606 1xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	
FS 03 / HP (materiaalaansluiting)	3606 2xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	
FS 03 / MP (bovenbeker)	3607 3xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	
FS 03 / MP (materiaalaansluiting)	3606 7xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	
<b>FineSpray 06-spuittipsets</b>														
FS 06 / HP (bovenbeker)	3606 3xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	✓	
FS 06 / HP (materiaalaansluiting)	3606 3xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	✓	
FS 06 / HP (onderbeker)	3606 3xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	✓	
FS 06 / MP (bovenbeker)	3606 4xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	✓	
FS 06 / MP (materiaalaansluiting)	3606 4xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	✓	
<b>FineSpray 09-spuittipsets</b>														
FS 09 / HP (bovenbeker)	3604 9xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / HP (materiaalaansluiting)	3605 6xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / HP (onderbeker)	3605 6xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / MP (bovenbeker)	3605 9xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / MP (materiaalaansluiting)	3606 0xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / MP (onderdrukbekeer)	3605 0xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / LP (bovenbeker)	3605 7xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / LP (materiaalaansluiting)	3605 8xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
FS 09 / LP (onderdrukbekeer)	3605 8xx	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	
<b>FineSpray-Master-spuittipsets</b>														
FS-Master (bovendrukbekeer)	3606 5xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	-	
FS-Master (materiaalaansluiting)	3606 5xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	-	
FS-Master (onderdrukbekeer)	3606 5xx	-	✓	✓	✓	✓	✓	✓	✓	-	✓	✓	-	



De FineSpray-spuittipsets bestaan uit:  
spuittip, naald en luchtkap